



Everlast Column Unit installation guidelines

1. Dig a footing for each column
2. Pour in a redi-mix concrete and level with a trowel .Allow 24 hrs for the concrete to dry and set up
- 3 Apply PL adhesive on top of concrete where column will be located
4. Set an Everlast column unit on top of pl and make sure unit is level
5. Apply PL adhesive to the top of the column unit and stack next section on top. Repeat this step to your desired height
6. Finish column by setting a column cap with PL adhesive on top of the final section

Optional (steel rebar can be added for additional strength thru inside hooks if desired)